



Changing the temperature on a **Beverage-Air Cross-Temp** unit is a simple and user friendly process:

1. The display will show the current temperature.
2. Press the “up” or “down” arrow to scroll from current temperature to desired temperature (meaning if the temperature displayed is 35 degrees, press the down arrow repeatedly until -10 is shown on the display, thus setting -10 as the new temperature set point).
3. After 30 seconds, the display automatically reverts to showing the current cabinet temperature, and will continue to adjust as temperature moves towards newly selected set point.

